

## BannerUp Plus ST Molded Shipping Case



1

BannerUp Plus to be loaded on its back edge, with the banner-slot up, and with the center pole mount facing the 'operator'- that is the person loading the unit in the case.



2

The poles for the Plus unit get stored in the canvas pole bag on the under-side of the bannerup, tucked in between & underneath the feet. Do this before loading the unit into the case.



3

Begin loading the BannerUp into the case by positioning the left end of the BannerUp fully into place, against the end foam and 'bottomed-out' in the case.



4

The right end of the unit is pushed into the case, the handle-end of the case can be flexed outward to allow the right end of the bannerup to squeeze down past the foam. For the first few uses, this will be a really tight fit.

